Printer

- Brother HL-L2300D Toner Reset

Brother HL-L2300D Toner Reset

The Brother HL-L2300D printer may report low toner when there is still toner left in the cartridge. This error will not always be resolved by replacing the toner. Complete the following steps to reset the toner counter.

1. **Press** and **Hold** the **Power** button until the machine turns off
2. **Open** the **Toner Door**
3. **Press** and **Hold** the **Go** button until **step 5**
4. **Press** the **Power** button
5. **Release** the **Go** button when the **Toner**, **Paper**, and **Drum** lights are lit
6. **Press** the **Go** button **9 times**
7. **Wait** for the **Toner**, **Paper**, and **Drum** lights to be lit
8. **Press** the **Go** button **5 times**
9. **Close** the **Toner Door**